## Side Curtain Measure Instructions

## **TOOLS REQUIRED**

- Measure Sheet
- Tape Measure
- Pen







QUESTIONS? PLEASE CONTACT US 0800 244 266 Page 1



Select the correct measure sheet: Truck, Trailer or Step Deck. Download measure sheets from www.straitline.co.nz/measurecurtains.

Fill out the contact details and specifications. The following specifications must be filled out:

- Fabric colour (you can see the options at <u>www.straitline.co.nz/transport9000</u>)
- Tensioner locations
- Curtain track type (this determines which roller size we'll use. Check the body builder: only Fruehauf track uses Small Rollers)
- Curtain type (Dry Freight = Single Skin)
- Curtain end type
- Buckle strap colour
- Rave hook type (this is the hook at the end of the buckle strap: Small (23mm) is for attaching to the coaming rail, Large (35mm) is for attaching to the rope rail)

2

Measure the curtain length. The length must be measured from the centre of the front pole to the centre of the rear pole (see pictures). If the poles are not in place, measure from where the centre of the pole will be (i.e. in line with the centre of the tensioner pin).

We attach hooks to the end of our tape measures, so the zero mark is in the correct location – contact us to find out how.





## Side Curtain Measure Instructions

- 3 Measure the buckle spacings. Simply hold the tape measure in place (if you're alone, use duct tape) and write the measurement from the front of the curtain to the centre of each buckle. Buckles are usually spaced around 600mm apart. Check to make sure there won't be any obstructions (e.g. lights) in the way of any buckle straps and check that no buckle strap is over a wheel, or on an angle.
- 4

SD

Measure the height. Hook your tape measure into the inside of the curtain track, close to one end of the curtain. Measure down to the bottom

of the coaming rail (see pictures).

Also note on the plans if there are any reinforcements required (e.g. support pole reinforcements) or any cutouts needed (e.g. over a wheel arch). You don't need to specify cutouts for tensioner handles, unless they need to be larger than 250mm.

## **Step Deck Curtains**

Please get the following extra measurements:

- Curtain heights at both front and rear
- Height of the step
- Distances from the centre of the front pole to the step, and from the centre of the rear pole to the step





0800 244 266

Page 2