

Shadetex Shade Mesh

Cleaning Instructions

Follow these instructions to clean Shadetex 370 or Shadetex 320 shade mesh.

1. Lay out fabric on flat smooth concrete. Be careful not to snag or drag the fabric.
2. Wet the fabric.
3. Evenly spray on a diluted mix of XT88 Commercial Truck Wash, 30seconds, or similar. We recommend testing your mix in a small, discrete area first.
4. Waterblast with a patio cleaner. If the sail is very dirty you may have to do this both sides, but usually only the underside.
5. Hang it up and hose off any debris.
6. Dry thoroughly.
7. Check thread is still holding strong and look for holes, damages, etc. If the Shade Sail requires repairs, you can contact us on 0800 244 266.

