

Shade Sail Installation

(Webbing Edge)

Tools Required

- Adjustable spanner
- Ratchet & strap

Step 1

Lay the Shade Sail out on the ground, in the same position it will be in when installed. Check each corner is by the correct pole/bracket.

Step 2


Shackle a length of chain to each corner.

Step 3

Starting with the corner that is the most difficult to access, shackle the chain to the pole. To ensure your shade sail is positioned correctly, use the full chain length supplied until step 5 (i.e. don't shorten the chain yet).

WARNING

Do not attempt installation in windy conditions, as the shade sail will be difficult to control.







Step 4

Use the ratchet & strap to attach the remaining corners. Secure the ratchet strap around the pole, as shown (note: if you have an endless strap, instead of a double hook strap, simply feed the webbing through the shackle and the eyebolt). Tighten each corner until you can attach the chain to the eyebolt, then remove the ratchet.



Step 5

On the last corner, tension the ratchet until the shade sail is tight. Shackle the chain to the pole at the required length. There will be excess links, like those circled in red on the image. We recommend leaving them attached in case you need to adjust the shade sail later.

Step 6

Ensure the Shade Sail is 'drum-tight' and cannot flap in high winds. You may need to re-tension in 1-2 months, after the fabric has settled.

