

Euromesh

Cleaning Instructions

Euromesh consists of a polyester base cloth with a PVC coating. As with any fabric, it is important that there is some degree of maintenance, to keep the product looking at its best for the designed life of the material. Fabrics used in any application can encounter some dirt build up due to atmospheric pollution, dust, birds, and other environmental factors.

Cleaning

If the surface is stained, the recommended cleaning method is to use a neutral detergent in warm water. Apply it to the surface with a soft sponge or mop and flush with sufficient water. Solvent based cleaners should not be used. These can attack the coatings used in these materials. Abrasive cleaning agents should not be used because these can damage the top surface of the fabric. Ensure your Euromesh product is completely dry before rolling or storing.

